



304 Blue Mountain Road
Saugerties, NY 12477
(866) 834-5674

www.advancedcarbonsystems.com

Installation Instructions for Vent Pipe Odor Filter

1. Carefully unpack the vent pipe filter. Inspect it for damage and report any damage immediately to your distributor.
2. Remove nut, washer and rain cap on the top of the unit.
3. Fill vent pipe filter to a level just beneath the top vent holes .
4. Even out the carbon in the filter and replace rain cap, washer and nut.
5. Secure the carbon vent filter to the sewer vent pipe with two set screws.

Maintenance Instructions

The life of the carbon depends upon the odor concentration and air flow rate from the sewer. In between carbon change out, there is no maintenance required. When the carbon is spent:

1. Remove vent filter from the sewer vent pipe.
2. Remove rain hat and dump out spent carbon
3. Properly dispose of spent carbon in accordance with local landfill regulations.
4. Refill the filter with fresh carbon (available in 40lb sacks from ACS.)
5. Replace rain hat.
6. Reinstall vent filter on vent pipe.