



Notes:

1. Sheet may be trimmed up to 4" beyond frame before addition of concrete
2. Place a continuous bead of an approved silicone sealant between frame and polyethylene sheet.

